

OWNER'S MANUAL & OPERATING INSTRUCTIONS



8250 Starting Watts / 6500 Rated Watts Wireless Remote Electric Start

PORTABLE GENERATOR



41332

SAVE THESE INSTRUCTIONSImportant Safety Instructions are included in this manual.

10006 Santa Fe Springs Road Santa Fe Springs CA 90670 USA / 1-877-338-0999 www.championpowerequipment.com

Have questions or need assistance?

Do not return this product to the store!

WE ARE HERE TO HELP!


Visit our website: www.championpowerequipment.com for more info:

- Product Info & Updates
- Tech Bulletins
- Frequently Asked Questions
 Product Registration

– or –

Call our Customer Care Team Toll-Free at:

1-877-338-0999



8250 Starting Watts / 6500 Rated Watts Wireless Remote Electric Start PORTABLE GENERATOR

TABLE OF CONTENTS

Introduction	Maintenance and Storage
Introduction	Engine Maintenance
Portable Power Generator	Oil
Accessories	Spark Plugs
This Booklet1	Air Filter
Manual Conventions	Spark Arrester
Safety Rules	Cleaning
Controls and Features 5	Adjustments
Generator	Maintenance Schedule 16
Power Panel 6	Generator Maintenance 17
Wireless Remote Control 7	Storage
Remote Control Power Consumption 7	Generator Storage
Power Panel Load Management 7	Disconnect the Battery 17
Parts Included	Charge the Battery 17
Wheel Kit 8	Specifications
Other	Engine Specifications
Assembly	Generator Specifications
Remove the Generator from the Shipping Carton 9	Fuel
Install the Wheel Kit 9	0il
Install the Support Leg 9	Spark Plugs
Connect the Battery 9	Valve Clearance
Add Engine Oil	FCC Statement for Remote Control Device 18
Add Fuel	Parts Diagram 19
Grounding	Parts List
Operation	Engine Parts Diagram 21
Generator Location	Engine Parts List
Grounding	Wiring Diagram
Surge Protection	Troubleshooting
Wireless Remote Start	Warranty
Starting the Engine without Remote 12	Warranty Qualifications
Connecting Electrical Loads 13	Repair/Replacement Warranty
Stopping the Engine	Do Not Return The Unit To
Do Not Overload Generator	The Place Of Purchase
Capacity	Warranty Exclusions
Power Management	Normal Wear
Operation at High Altitude	Installation, Use and Maintenance 25
.,	Other Exclusions
	Limits of Implied Warranty
	and Consequential Damage 25
	Contact Information
	Address
	Customer Service
	Technical Service

INTRODUCTION

Introduction

Congratulations on your purchase of a Champion Power Equipment generator. CPE designs and builds generators to strict specifications. With proper use and maintenance, this generator will bring years of satisfying service.

Portable Power Generator

This unit is a gasoline engine driven, alternating current (AC) generator. It is designed to supply electrical power for lighting, appliances, tools and similar equipment.

Accessories

Champion Power Equipment manufactures and sells accessories designed to help you get the most from your purchase. To find out more about our covers, power cables and storm kits, please visit our web site at:

→ www.championpowerequipment.com

This Booklet

Every effort has been made to ensure the accuracy and completeness of the information in this manual. We reserve the right to change, alter and/or improve the product and this document at any time without prior notice.

Record the model and serial numbers as well as date and place of purchase for future reference. Have this information available when ordering parts and when making technical or warranty inquiries.



MANUAL CONVENTIONS

This manual uses the following symbols to help differentiate between different kinds of information. The safety symbol is used with a key word to alert you to potential hazards in operating and owning power equipment. Follow all safety messages to avoid or reduce the risk of serious injury or death.

\land DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

⚠WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

(I) CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

CAUTION

CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.

NOTE

If you have questions regarding your generator, we can help. Please call our help line at 1-877-338-0999.

⚠ WARNING

Read this manual thoroughly before operating your generator. Failure to follow instructions could result in serious injury or death.

∕N WARNING

The engine exhaust from this product contains chemicals known to the state of California to cause cancer, birth defects, or other reproductive harm.

\Lambda DANGER

Generator exhaust contains carbon monoxide, a colorless, odorless, poison gas. Breathing carbon monoxide will cause nausea, dizziness, fainting or death. If you start to feel dizzy or weak, get to fresh air immediately.

Operate generator outdoors only in a well ventilated

DO NOT operate the generator inside any building, including garages, basements, crawlspaces and sheds, enclosure or compartment, including the generator compartment of a recreational vehicle. DO NOT allow exhaust fumes to enter a confined area through windows, doors, vents or other

DANGER CARBON MONOXIDE: using a generator indoors CAN KILL YOU IN MINUTES.

A DANGER

Rotating parts can entangle hands, feet, hair, clothing and/or accessories.

Traumatic amputation or severe laceration can result.

Keep hands and feet away from rotating parts. Tie up long hair and remove jewelry. Operate equipment with guards in place. DO NOT wear loose-fitting clothing, dangling drawstrings or items that could become caught.

\land DANGER

Generator produces powerful voltage.

DO NOT touch bare wires or receptacles.

DO NOT use electrical cords that are worn, damaged or frayed.

DO NOT operate generator in wet weather.

DO NOT allow children or unqualified persons to operate or service the generator

Use a ground fault circuit interrupter (GFCI) in damp areas and areas containing conductive material such as metal decking.

Use approved transfer equipment to isolate generator from your electric utility and Notify your utility company before connecting your generator to your power system.

⚠ WARNING

Sparks can result in fire or electrical shock.

When servicing the generator:

Disconnect the spark plug wire and place it where it cannot contact the plug.

DO NOT check for spark with the plug removed. Use only approved spark plug testers.

⚠ WARNING

Running engines produce heat. Severe burns can occur on contact.

Combustible material can catch fire on contact.

DO NOT touch hot surfaces.

Avoid contact with hot exhaust gases.

Allow equipment to cool before touching.

Maintain at least three feet of clearance on all sides to ensure adequate cooling.

Maintain at least five feet of clearance from combustible materials.

⚠ WARNING

Medical and Life Support Uses.

In case of emergency, call 911 immediately. NEVER use this product to power life support devices or life support appliances.

NEVER use this product to power medical devices or medical appliances.

Inform your electricity provider immediately if you or anyone in your household depends on electrical euipment to live.

Inform your electrical provider immediately if a loss of power would cause you or anyone in your household to experience a medical emergency.

\land DANGER

Fuel and fuel vapors are highly flammable and extremely explosive.

Fire or explosion can cause severe burns or death. Unintentional startup can result in entanglement, traumatic amputation or laceration.

When adding or removing fuel:

Turn the generator off and let it cool for at least two minutes before removing the fuel cap. Loosen the cap slowly to relieve pressure in the tank.

Only fill or drain fuel outdoors in a well-ventilated area. DO NOT pump gas directly into the generator at the gas station. Use an approved container to transfer the fuel to the generator.

DO NOT overfill the fuel tank.

Always keep fuel away from sparks, open flames, pilot lights, heat and other sources of ignition. DO NOT light or smoke cigarettes.

When starting the generator:

DO NOT attempt to start a damaged generator. Make certain that the gas cap, air filter, spark plug, fuel lines and exhaust system are properly in place. Allow spilled fuel to evaporate fully before attempting to start the engine.

Make certain that the generator is resting firmly on level ground.

When operating the generator:

DO NOT move or tip the generator during operation. DO NOT tip the generator or allow fuel or oil to spill.

When transporting or servicing the generator:

Make certain that the fuel shutoff valve is in the off position and the fuel tank is empty.

Disconnect the spark plug wire.

When storing the generator:

Store away from sparks, open flames, pilot lights, heat and other sources of ignition.

⚠ WARNING

Operation of this equipment may create sparks that can start fires around dry vegetation.

A spark arrestor may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

⚠ WARNING

Rapid retraction of the starter cord will pull hand and arm towards the engine faster than you can let go. Unintentional startup can result in entanglement, traumatic amputation or laceration.

Broken bones, fractures, bruises or sprains could result.

When starting engine, pull the starter cord slowly until resistance is felt and then pull rapidly to avoid kickback.

DO NOT start or stop the engine with electrical devices plugged in.

(1) CAUTION

Exceeding the generator's running capacity can damage the generator and/or electrical devices connected to it.

DO NOT overload the generator.

Start the generator and allow the engine to stabilize before connecting electrical loads.

Connect electrical equipment in the off position, and then turn them on for operation.

Turn electrical equipment off and disconnect before stopping the generator.

DO NOT tamper with the governed speed.

DO NOT modify the generator in any way.

(!) CAUTION

Improper treatment or use of the generator can damage it, shorten its life and void your warranty.

Use the generator only for intended uses.

Operate only on level surfaces.

DO NOT expose generator to excessive moisture, dust. or dirt.


DO NOT allow any material to block the cooling slots. If connected devices overheat, turn them off and disconnect them from the generator.

DO NOT use the generator if:

- Electrical output is lost
- Equipment sparks, smokes or emits flames
- Equipment vibrates excessively


CONTROLS AND FEATURES

Read this owner's manual before operating your generator. Familiarize yourself with the location and function of the controls and features. Save this manual for future reference.



- Fuel Tank -5.9 gallon (22.4 L) capacity fuel tank. (1)
- (2) Auto-Choke – Used to start the engine. No manual adjustment required.
- (3) Fuel Valve – Used to turn fuel supply on and off to engine.
- (4) **Air Cleaner** – Protects the engine by filtering dust and debris from the intake air.
- **Recoil Starter** Used to manually start the engine. (5)
- (6) Oil Filler Cap – Check and fill engine oil level.
- (7) **Battery** – Used to start the engine. Provides 12V DC to the electric starter and receiver control module.
- Power Panel See "Power Panel" section. (8)

Power Panel



- (1) Battery Switch - Enables/disables starting electrically – via remotely or by Ignition Switch.
- Ignition Switch Used to start or stop the (2) generator.
- (3) **Voltmeter** – Used to display alternator output voltage.
- (4) **Circuit Breakers** – Protects the generator against electrical overloads. Push to reset breaker.
- (5) **Remote Reset** – May be used to reprogram existing or program new remote controls.
- (6) 120 Volt AC, 30 Amp Twist-Lock Receptacle (NEMA L5-30R) – May be used to supply electrical power for the operation of 120 Volt AC, 30 Amp, single phase 60 Hz electrical loads.

- (7) 120/240 Volt AC, 30 Amp Twist-Lock Receptacle (NEMA L14-30R) – May be used to supply electrical power for the operation of 120 and/or 240 Volt AC, 30 Amp, single phase 60 Hz electrical loads.
- 120 Volt AC, 20 Amp Duplex (2) (8) (NEMA 5-20R) – May be used to supply electrical power for the operation of 120 Volt AC, 20 Amp, single phase 60 Hz electrical loads.
- (9) **Ground Terminal** – Consult an electrician for local grounding regulations.

CONTROLS AND FEATURES

Wireless Remote Control

This generator is equipped with a wireless remote control system for starting and stopping. The system consists of (4) main components:

- 1. Receiver Control Module (RCM)
- 2. Wireless Remote
- 3. Battery Switch
- 4. Ignition Switch

The Remote Control functions are enabled when:

- 1. The Ignition Switch is in the "ON" position, AND
- 2. The Battery Switch is in the "ON" position.

The Remote Control functions are disabled if either of the above conditions is not met.

To start the generator by Remote Control, press the "START" button on the Remote one time. The engine will attempt to start (6) times. The RCM controls the Auto Choke during each attempt to start. If the generator does not start, call Champion Customer Care team for assistance at 1-877-338-0999.

To stop the generator by Remote Control, press the "STOP" button on the Remote one time.

Remote Control Power Consumption

While the Ignition Switch is in the "ON: position, the RCM is active and waiting for a remote signal. This function requires electrical current from the battery. If the Ignition Switch is left in the "ON" position for extended periods (several weeks), the battery can be completely drained.

Moving the Ignition Switch to the "OFF" position disables the Remote functions, but the RCM still consumes approximately 2 mA from the battery. To prevent battery drain, press the Battery Switch to the "OFF" position. This disconnects power to the RCM so there is no current draw on the battery.

Power Panel Load Management

When the generator initially starts by the Remote, no voltage is supplied to the Power Panel for approximately 15 seconds. This allows the engine to reach full speed before electrical loads are applied to the generator. When the generator is stopped by the Remote, the voltage to the Power Panel is immediately turned off. Then the engine stops after the "STOP" button on the Remote is pressed. Turning the Power Panel voltage off before the engine shutdown protects connected appliances from being damaged by non-60 Hz voltage while the generator coasts to a stop.

Power Panel Load Management Cont'd.

The on/off voltage delay at startup only happens when the Remote Control is used. There is no voltage delay when the pushbutton electric start or recoil start method is used.

When the pushbutton electric start or recoil start method is used, the operator must be sure all electrical loads (appliances) are turned OFF during startup and shutdown. Damage to the generator or the attached appliances can be caused by starting or stopping the generator while appliances are plugged in and turned ON.


CONTROLS AND FEATURES

Parts Included

Your 41332 Gasoline Powered Generator ships with the following parts:

Wheel Kit

_	10" Wheel
-	Flange Bolt (M10x115 for Wheel) 2
-	Bushing
-	Flat Washer 10
-	Nut (M10)
-	Support Leg w/Vibration Mounts
-	Flange Bolt (M8x16 for Support Leg) 2
-	Nut (M8)
0t	her
_	Remote
-	Cap Screw (M5x12 for Battery Terminals) 2
_	Nut (M5)



ASSEMBLY

Your generator requires some assembly. This unit ships from our factory without oil. It must be properly serviced with fuel and oil before operation.

If you have any questions regarding the assembly of your generator, call our help line at 1-877-338-0999. Please have your serial number and model number available.

Remove the Generator from the Shipping Carton

- 1. Set the shipping carton on a solid, flat surface.
- 2. Remove everything from the carton except the generator.
- 3. Carefully cut each corner of the box from top to bottom. Fold each side flat on the ground to provide a surface area to install the wheel kit and support leg.


Install the Wheel Kit



The wheel kit is not intended for over-the-road use.


You will need the following tools to install the wheels:

- 17 mm wrench OR adjustable wrench (not included)
- Socket wrench with a 16 mm socket (not included)
- Pliers (not included)
- 1. Before adding fuel and oil, tip the generator on it's side.
- 2. Slide the M10x115 wheel bolt through the washer, sleeve and wheel.
- 3. Slide the bolt through the mount point on the frame.
- 4. Fasten securely with the M10 nut.
- 5. Repeat steps 2-4 to attach the second wheel.



Install the Support Leg

- 1. Attach the support leg to the generator frame with cap screws (M8x16) and nuts (M8).
- 2. Tip the generator slowly so that it rests on the wheels and support leg.



Connect the Battery

- 1. Remove the protective cover from the red (+) lead on the battery.
- 2. Attach the red (+) lead to the red (+) terminal on the battery with the cap screw (M5x12) and secure with the lock washer (M5).
- 3. Repeat steps 1-2 for the black (-) battery lead.

Add Engine Oil


! CAUTION

DO NOT attempt to crank or start the engine before it has been properly filled with the recommended type and amount of oil. Damage to the generator as a result of failure to follow these instructions will void your warranty.




The recommended oil type is 10W-30 4-cycle automotive oil.

1. Place the generator on a flat, level surface.



- 2. Remove oil fill cap/dipstick to add oil.
- 3. Add 1.16 qt. (1.1 L) of oil and replace oil fill cap/ dipstick.



4. Check engine oil level daily and add as needed.

Add Engine Oil Cont'd.

CAUTION

The engine is equipped with a low-oil-shutoff and will stop when the oil level in the crankcase falls below the threshold level.



♥ NOTE


Check oil often during the break-in period. Refer to the Maintenance section for recommended service intervals.



The generator rotor has a sealed, pre-lubricated ball bearing that requires no additional lubrication for the life of the bearing.

Add Fuel

- 1. Use clean, fresh, regular unleaded fuel with a minimum octane rating of 85 and an ethanol content of less than 10% by volume.
- 2. DO NOT mix oil with fuel.
- 3. Clean the area around the fuel cap.
- 4. Remove the fuel cap.
- 5. Slowly add fuel to the tank. DO NOT overfill. Allow approximately \(\frac{1}{4} \) inch of space for fuel expansion.



6. Screw on the fuel cap and wipe away any spilled fuel.

(I) CAUTION

Use regular unleaded gasoline with a minimum octane rating of 85.

Do not mix oil and gasoline.

Fill tank to approximately 1/4" below the top of the tank to allow for fuel expansion.

DO NOT pump gas directly into the generator at the gas station. Use an approved container to transfer the fuel to the generator.

DO NOT fill fuel tank indoors.

DO NOT fill fuel tank when the engine is running or hot.

DO NOT overfill the fuel tank.

DO NOT light cigarettes or smoke when filling the fuel tank.

⚠ WARNING

Pouring fuel too fast through the fuel screen may result in blow back of fuel at the operator while filling.

Grounding

Your generator must be properly connected to an appropriate ground to help prevent electric shock.



Failure to properly ground the generator can result in electric shock.

A ground terminal connected to the frame of the generator has been provided on the power panel. For remote grounding, connect of a length of heavy gauge (12 AWG minimum) copper wire between the generator ground terminal and a copper rod driven into the ground. We strongly recommend that you consult with a qualified electrician to ensure compliance with local electrical codes.

Generator Location

Please consult your local authority. In some areas, generators must be registered with the local utility. Generators used at construction sites may be subject to additional rules and regulations.

This generator must have at least five feet of clearance from combustible material. Leave at least three feet of clearance on all sides of the generator to allow for adequate cooling, maintenance and servicing. Place the generator in a well-ventilated area. DO NOT place the generator near vents or intakes where exhaust fumes could be drawn into occupied or confined spaces. Carefully consider wind and air currents when positioning generator.



Do not operate or store the generator in rain, snow, or wet weather.

Using a generator or electrical appliance in wet conditions, such as rain or snow, or near a pool or sprinkler system, or when your hands are wet, could result in electrocution.

Grounding

The generator system ground connects the frame to the ground terminals on the power panel.

- The generator (stator winding) is isolated from the frame and from the AC receptacle ground pin.
- Electrical devices that require a grounded receptacle pin connection may not function properly.

Surge Protection

CAUTION

Voltage fluctuation may impair the proper functioning of sensitive electronic equipment.

Electronic devices, including computers and many programmable appliances use components that are designed to operate within a narrow voltage range and may be affected by momentary voltage fluctuations. While there is no way to prevent voltage fluctuations, you can take steps to protect sensitive electronic equipment.

1. Install UL1449, CSA-listed, plug-in surge suppressors on the outlets feeding your sensitive equipment. Surge suppressors come in single- or multi-outlet styles. They're designed to protect against virtually all short-duration voltage fluctuations.

Wireless Remote Start

Wireless remote starting is only possible within 80 feet of the generator.

Do not attempt to adjust the carburetor choke. The remote system will automatically close and open the choke.

- 1. Make certain the generator is on a flat, level surface.
- 2. Press the Ignition Switch to "ON".
- 3. Press the Battery Switch to "ON".
- 4. Turn the Fuel Valve to the "ON" position.
- 5. To start the engine, press and release the "START" button on the handheld Remote Control device. DO NOT hold the button down, only press the button once. The engine will attempt to start 6 times.
- 6. A safety feature is provided which delays the electrical power availability during starting mode. The delay lasts for approximately 15 seconds. The delay is provided to prevent damage to the generator if electrical loads are inadvertently turned on during engine startup.
- 7. If the generator fails to start, see trouble shooting.

Starting the Engine without Remote

- 1. Make certain the generator is on a flat, level surface.
- 2. Turn off all electrical loads connected to the generator. Never start or stop the generator with electrical devices plugged in and turned on.
- 3. Turn the Fuel Valve to the "ON" position.
- 4. Press the Battery Switch to "ON".
- 5. ELECTRIC START: Press and hold ignition switch in the "Start" position until the engine starts. When the engine starts release the ignition switch allowing it to settle to the "Run" position. Holding down the ignition switch for longer than 5 seconds can damage the starter motor. If the engine fails to start after 5 seconds release the switch and wait at least 10 seconds before attempting to start the engine again.
- 6. RECOIL START: Pull the starter cord slowly until resistance is felt and then pull rapidly.



If the engine starts but does not run make certain that the generator is on a flat, level surface. The engine is equipped with a low oil sensor that will prevent the engine from running when the oil level falls below a critical threshold.

OPERATION

Connecting Electrical Loads

- 1. Let the engine stabilize and warm up for a few minutes after starting
- 2. Plug in and turn on the desired 120/240 Volt AC single phase, 60 Hz electrical loads.
- DO NOT connect 3-phase loads to the generator.
- DO NOT connect 50 Hz loads to the generator.
- DO NOT overload the generator.



Connecting a generator to your electric utility company's power lines or to another power source may be against the law. In addition this action, if done incorrectly, could damage your generator and appliances and could cause serious injury or even death to you or a utility worker who may be working on nearby power lines. If you plan to run a portable electric generator during an outage, please notify your electric utility company immediately and remember to plug your appliances directly into the generator. Do not plug the generator into any electric outlet in your home. Doing so could create a connection to the utility company power lines. You are responsible for ensuring that your generator's electricity does not feed back into the electric utility power lines.

If the generator will be connected to a building electrical system, consult your local utility company or a qualified electrician. Connections must isolate generator power from utility power and must comply with all applicable laws and codes.

Stopping the Engine

- 1. Turn off all electrical loads connected to the generator. Never start or stop the generator with electrical devices plugged in and turned on.
- 2. Press and release the STOP button on the Remote Control device OR turn the Ignition Switch to the "OFF" position.
- 3. Turn the Fuel Valve to the "OFF" position.

Important: If the generator will be moved or stored turn the Fuel Valve to the "OFF" position, press the Ignition Switch and the Battery Switch on the power panel to the "OFF" position.

Do Not Overload Generator

Capacity

Follow these simple steps to calculate the running and starting watts necessary for your purposes.

- 1. Select the electrical devices you plan on running at the same time.
- 2. Total the running watts of these items. This is the amount of power you need to keep your items running.
- 3. Identify the highest starting wattage of all devices identified in step 1. Add this number to the number calculated in step 2. Surge wattage is the extra burst of power needed to start some electric driven equipment. Following the steps listed under "Power Management" will guarantee that only one device will be starting at a time.

Power Management

Use the following formula to convert voltage and amperage to watts:

Volts x Amps = Watts

To prolong the life of your generator and attached devices, follow these steps to add electrical load:

- 1. Start the generator with no electrical load attached
- 2. Allow the engine to run for several minutes to stabilize.
- 3. Plug in and turn on the first item. It is best to attach the item with the largest load first.
- 4. Allow the engine to stabilize.
- 5. Plug in and turn on the next item.
- 6. Allow the engine to stabilize.
- 7. Repeat steps 5-6 for each additional item.



Never exceed the specified capacity when adding loads to the generator.

Operation at High Altitude

The density of air at high altitude is lower than at sea level. Engine power is reduced as the air mass and airfuel ratio decrease. Engine power and generator output will be reduced approximately 3½% for every 1000 feet of elevation above sea level. This is a natural trend and cannot be changed by adjusting the engine. At sufficiently high altitudes increased exhaust emissions can also result due to the increased enrichment of the air fuel ratio. Other high altitude issues can include hard starting, increased fuel consumption and spark plug fouling.

To alleviate high altitude issues other than the natural power loss, Champion Power Equipment can provide a high altitude carburetor main jet. The alternative main jet and installation instructions can be obtained by contacting Customer Support. Installation instructions are also available in the Technical Bulletin area of the Champion Power Equipment internet site.

The part number and recommended minimum altitude for the application of the high altitude carburetor main jet is listed in the table below.

	Part Number	Altitude
Standard main jet	ST188FD-1131000-17	4000 Feet
Altitude main jet	188.131017.01	(1200 Meters)

↑ WARNING

Operation using the alternative main jet at elevations lower than the recommended minimum altitude can damage the engine. For operation at lower elevations, the standard main jet must be used. Operating the engine with the wrong engine configuration at a given altitude may increase its emissions and decrease fuel efficiency and performance.

MAINTENANCE AND STORAGE

The owner/operator is responsible for all periodic maintenance.

⚠ WARNING

Never operate a damaged or defective generator.

⚠ WARNING

Tampering with the factory set governor will void your warranty.

↑ WARNING

Improper maintenance will void your warranty.



Maintenance, replacement, or repair of emission control devices and systems may be performed by any non-road engine repair establishment or individual.

Complete all scheduled maintenance in a timely manner. Correct any issue before operating the generator.



For service or parts assistance, contact our help line at 1-877-338-0999

Engine Maintenance

To prevent accidental starting, remove and ground spark plug wire before performing any service.

0il


Change oil when the engine is warm. Refer to the oil specification to select the proper grade of oil for your operating environment.

- 1. Remove the oil drain plug with a 12 mm socket and extension.
- 2. Allow the oil to drain completely.
- 3. Replace the drain plug.
- 4. Remove oil fill cap/dipstick to add oil.
- 5. Add 1.16 qt. (1.1 L) of oil and replace oil fill cap/dipstick.
- 6. Dispose of used oil at an approved waste management facility.

Oil Cont'd.


◯ NOTE

Once oil has been added, a visual check should show oil about 1-2 threads from running out of the fill hole. If using the dipstick to check oil level, DO NOT screw in the dipstick while checking.



Spark Plugs

- 1. Remove the spark plug cable from the spark plug.
- 2. Use a 13/16" or 21 mm socket to remove the plug.
- 3. Inspect the electrode on the plug. It must be clean and not worn to produce the spark required for ignition.
- 4. Make certain the spark plug gap is 0.7 0.8mm or (0.028 - 0.031 in.).



- 5. Refer to the spark plug recommendation chart when replacing the plug.
- 6. Carefully thread the plug into the engine.
- 7. Use the spark plug tool to firmly install the plug.
- 8. Attach the spark plug wire to the plug.


Air Filter

- 1. Remove the snap-on cover holding the air filter to the assembly.
- 2. Remove the foam element.
- 3. Wash in liquid detergent and water. Squeeze thoroughly dry in a clean cloth.
- 4. Saturate in clean engine oil.
- 5. Squeeze in a clean, absorbent cloth to remove all excess oil.
- 6. Place the filter in the assembly.
- 7. Reattach the air filter cover and snap in place.

MAINTENANCE AND STORAGE

Spark Arrester

- 1. Allow the engine to cool completely before servicing the spark arrester.
- 2. Remove the three screws holding the cover plate which retains the end of the spark arrester to the muffler.
- 3. Remove the spark arrester screen.
- 4. Carefully remove the carbon deposits from the spark arrester screen with a wire brush.
- 5. Replace the spark arrester if it is damaged.
- 6. Position the spark arrester in the muffler and attach with the three screws.



① CAUTION

Failure to clean the spark arrester will result in degraded engine performance.



Federal and local laws and administrative requirements indicate when and where spark arresters are required. When ordered, spark arresters are required for operation of this generator in National Forest lands. In California, this generator must not be used on any forest- covered land, brush-covered land, or grass- covered land unless the engine is equipped with a spark arrester.

Cleaning



(1) CAUTION

DO NOT spray engine with water.

Water can contaminate the fuel system.

Use a damp cloth to clean exterior surfaces of the engine. Use a soft bristle brush to remove dirt and oil.

Use an air compressor (25 PSI) to clear dirt and debris from the engine.

Adjustments

The air-fuel mixture is not adjustable. Tampering with the governor can damage your generator and your electrical devices and will void your warranty. CPE recommends that you contact our service line at 1-877-338-0999 for all other service and/or adjustment needs.

Maintenance Schedule

Follow the service intervals indicated in the following maintenance schedule.

Service your generator more frequently when operating in adverse conditions.

Contact our helpline at 1-877-338-0999 to locate the nearest Champion Power Equipment certified service dealer for your generator or engine maintenance needs.

Every 8 hours or daily		
Check oil level		
Clean around air intake and muffler		
First 5 Hours		
Change oil		
Every 50 hours or every season		
Clean air filter		
Change oil if operating under heavy load or in hot environments		
Every 100 hours or every season		
Change oil		
Clean/Adjust spark plug		
Check/Adjust valve clearance *		
Clean spark arrester		
Clean fuel tank and filter *		
Every 250 hours		
Clean combustion chamber*		
Every 3 years		
Replace fuel line		

^{*}To be performed by knowledgeable, experienced owners or Champion Power Equipment certified dealers.

MAINTENANCE AND STORAGE

Generator Maintenance

Make certain that the generator is kept clean and stored properly. Only operate the unit on a flat, level surface in a clean, dry operating environment. DO NOT expose the unit to extreme conditions, excessive dust, dirt, moisture or corrosive vapors.



(!) CAUTION

DO NOT use a garden hose to clean the generator.

Water can enter the generator through the cooling slots and damage the generator windings.

Use a damp cloth to clean exterior surfaces of the generator. Use a soft bristle brush to remove dirt and oil.

Use an air compressor (25 PSI) to clear dirt and debris from the generator.

Inspect all air vents and cooling slots to ensure that they are clean and unobstructed.

Storage

The generator should be started at least once every 14 days and allowed to run for at least 20 minutes. For longer term storage, please follow these guidelines.

Generator Storage

- 1. Allow the engine to cool completely before storage.
- 2. Clean the generator according to the instructions in the Maintenance section.
- 3. Turn the Fuel Valve to the "OFF" position.
- 4. Be sure all appliances are disconnected from the generator. Start the engine and let it run until the fuel in the line and the carburator is consumed and the engine dies.
- 5. Press the Battery Switch to "OFF".
- 6. Add a fuel stabilizer into the fuel tank.
- 7. Change the oil.
- 8. Remove the spark plug and pour about ½ ounce of oil into the cylinder. Crank the engine slowly to distribute the oil and lubricate the cylinder.
- 9. Reattach the spark plug.
- 10. Store the unit in a clean, dry place out of direct sunlight.

A DANGER

Generator exhaust contains odorless and colorless carbon monoxide gas.

To avoid accidental or unintended ignition of your remote start generator during periods of storage, the following precautions should be followed:

- When storing the generator for short periods of time make sure that the Ignition Switch, the Fuel Valve and the Battery Switch are set in the OFF position.
- When storing the generator for extended periods of time make sure that the Ignition Switch, the Fuel Valve and the Battery Switch are set in the the the **OFF** position and the battery leads have been disconnected from the battery.

Disconnect the Battery

- 1. Remove the protective cover from the black/negative battery lead.
- 2. Disconnect the black/negative lead from the black/ negative terminal on the battery and store the cap screw (M5x12) and lock washer (M5).
- 3. Repeat steps 1-2 for the red/positive battery lead.
- 4. Store the battery in a cool, dry place.

Charge the Battery

For generators equipped with batteries for electric starting, proper battery maintenance and storage should be followed. An automatic battery charger with automatic trickle charging capability should be used to charge the battery. Maximum charging rate should not exceed 1.5 amps. Follow the instructions included with the battery charger. The battery should be fully charged at least once per month.



NOTE

A Float Charger will maintain the battery condition over long storage periods.

Engine Specifications

-	Model
_	Displacement
_	Type
_	Start Type

Generator Specifications

_	Running Wattage
-	Starting Wattage
-	AC Load
-	Phase
-	Frequency
-	Fuel Capacity
-	Gross Weight
-	Net Weight
-	Height 26.3 inches (66.8 cm)
-	Width
_	Length

Fuel


Fuel capacity is 5.9 gal. (22.4 L). Use regular unleaded gasoline with a minimum octane rating of 85 and an ethanol content of less than 10% by volume.

Oil

Use 4-Cycle automotive oil.

Oil capacity is 1.16 qt. (1.1 L).

Please reference the following chart for recommended oil types for use in the generator.



Spark Plugs

OEM spark plug: NHSP F6RTC

Replacement spark plug: NGK BPR6ES or equivalent Make certain the spark plug gap is 0.7 - 0.8 mm or (0.028 - 0.031 in.).

Maintenance Valve Clearance

- Intake: 0.13 0.17 mm (0.005 0.007 in.)
- Exhaust: 0.18 0.22 mm (0.007 0.009 in.)

FCC Statement for Remote Control Device


- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.


Parts Diagram



"	Deal Newsley	B. and all an	01
#	Part Number	Description	Qty.
1	ST160F-1070007	Clamp	2
2	ST05FD-04712003-CARB	Air Cleaner Hose	1
3	ST168FD-1070408-CARB	Clamp	2
4	509.070014.00	Rollover Valve Hose	1
5	GB5789-FB8-12	Flange Bolt M8×12	4
6	ST05FD-04712100-CARB	Carbon Canister	1
7	ST05FD-04712005-CARB	Support Arm	1
8	ST05FD-04712002-CARB	90° Elbow	1
9	ST188FD-1070006A	Clip ø8	2
10	509.070011.01	Fuel Line, 8.9"	1
11	ST02FD-04160000	Fuel Cock	1
12	509.071000.35-Y	Fuel Tank	1
13	GB1667-S5-10	Screw M5×10	2
14	ST05FD-04711200-CARB	Fuel Meter Assembly	1
15	ST168F-1070400-K	Rollover Valve, KELCH	1
16	168.070100.01	Fuel Tank Cap	1
17	ST168F-1070006A	Fuel Filter	1
18	GB5789-FB6-20	Flange Bolt M6×20	4
19	GB93-LW-6	Lock Washer ø6	4
20	ST02FD-04100014	Washer ø6.5	4
21	ST02FD-04100010	Mount Rubber, Fuel Tank	4
22	ST188FD-1090006	Holder, Air Cleaner	1
23	GB41-N-6	Nut M6	3
24	GB90-W-8	Washer 8	2
25	GB93-LW-8	Lock Washer ø8	4
26	GB41-N-8	Nut M8	2
27	ST188FD-1100001-G	Gasket, Exhuast Pipe+G19409	1
28	188.101000.05	Muffler (CARB)	1
29	GB1667-S5-12	Screw M5×12	3
30	188.101500.31	Spark Arrester Assembly	1
31	GB5789-FB8-20	Flange Bolt M8×20	2
32	GB5789-FB6-12	Flange Bolt M6×12	2
33	ST168FD-1100003-CARB	Gasket, SAI Valve	1
34	ST168FD-1100300-CARB	SAI Valve	1
35	GB41-N-5	Nut M5	2
36	GB90-W-5	Washer 5	5
37	GB93-LW-5	Lock Washer ø5	5
38	ST05FD-1152007-5	Flange Bolt M5×201	2
39	GB90-W-6	Washer 6	6
40	GB93-LW-6	Lock Washer ø6	6
41	ST05FD-1152035-CSA	Carbon Brush Assembly	1
42	ST02FD-02100008	Brush Support Plate	1
43	GB5781-B5-20	Bolt M5×20	2
45	GB5789-FB5-12	Flange Bolt M5×12	1
46	ST05FD-1152001(Y) GB5781-B5-16	Generator End Cover Bolt M5×16	2
47	ST02FD-02100010	Terminal Block	1
48	GB5789-FB5-16	Flange Bolt M5×16	2
49	509.190200.01	AVR	1
50	ST05FD-1152002	End Housing	1
51	GB5789-FB6-179	Flange Bolt M6×179	4
52	ST188FD-1152003-5	Stator Cover	1
53	GB5789-FB10-1.25-265	Flange Bolt M10×1.25×265	1
54	ST05FD-1152010-5	Stator Assembly	1
55	GB93-LW-10	Lock Washer Ø10	1
56	GB90-W-10	Washer 10	1
57	ST05FD-1152020-5	Rotor Assembly	1
58	GB5789-FB6-8	Flange Bolt M6×8	2
59	ST05FD-1151600	Air Guide	1
60	ST05FD-1152008	Plug-A	1
61	ST05FD-1152009	Plug-B	1
		1 '0	

#	Part Number	Description	Qty.
62	188FDE-GC3	Engine	1
63	ST182FD-1742203-UC	Cover, Handle	1
64	509.200701.07	Handle	1
65	ST05FD-03161202	Bushing+G10424, Handle	2
66	GB896-B-6	Baffle ø6	2
67	ST182FD-1742002-UC	Pin	2
68	GB896-B-8	Baffle ø8	2
69	GB5789-FB8-35	Flange Bolt M8×35	2
70	GB96-FW-8	Flat Washer ø8	2
71	ST182FD-1742003-UC	Mount Rubber, End Housing	2
72	GB5789-FB6-12	Flange Bolt M6×12	6
73	ST02FD-1152010-5	Ground Wire	1
74	ST05FD-1151400-1	Motor Mount	1
75	GB41-N-8	Nut M8	8
76	ST05FD-1151300-1	Motor Mount I	1
77	GB41-N-10	Nut M10	2
78	GB41-N-10	Nut M10	2
79	ST05FD-0201-5(F)	Frame	1
80	ST188FD-1744002-T	Wheel	2
81	ST36QXG-03000002	Bushing 10.5×69.5	2
82	GB96-FW-10	Flat Washer 10	2
83	GB5781-B10-115	Bolt M10×115	2
84	GB41-N-5	Nut M5	2
85	FM12170	Battery 12V15AH	1
86	509.200904.00	Battery Strap	1
87	ST168FD-1750002-C6	Battery Wire, Positive	1
88	ST168FD-1750002-C5	Battery Wire, Negative	1
89	ST05FD-03011112	Battery Gromet	3
90	GB5789-FB8-16	Flange Bolt M8×16	2
91	ST05FD-03020301-84	Support Leg	1
92	ST188FD-1743002-C	Vibration Mount	2
93	GB5789-FB8-25	Flange Bolt M8×25	2
94	5A128E(F)	Control Panel	1
95	29.001.00	Switch	1
96	ST02FD-05612005	Pilot Lamp	1
97	ST02FD-05612004	Button	1
98	ST02FD-05502020	Receptacle L5-30R	1
	ST02FD-05502022	Receptacle L14-30R	1
100	ST02FD-05502023	Receptacle 5-20R	2
101	GB1667-S4-14	Screw M4×14	10
102	GB93-LW-4	Lock Washer ø4	8
102	GB95-LW-4 GB96-FW-4	Flat Washer 4	10
103	GB41-N-4	Nut M4	8
105	GB5781-B6-22	Bolt M6x22	1
106	GB41-N-6	Nut M6	2
107	GB90-W-6	Washer 6 Grommet, Panel Side	1
108	ST05FD-05215001	· · · · · · · · · · · · · · · · · · ·	1
109	ST05FD-05215009	Sheath, Wire	1
110	ST05FD-05215003	Grommet, Control Box Side	1
111	ST02FD-05302001-L20	A.C. 25A Breaker	2
112	ST02FD-05302001-L25	A.C 25A Breaker	2
113	GB1667-S5-14	Screw M5×14	2
114	0V01-00000000-1	Over Voltage Protector	1
115	ST02FD-05602010-D	Voltage Meter	1
116	EC02	Charger Module	1
117	21.001000.02	Switch, Battery	1
118	BG01-00000000	Rectifier	1
119	ST02FD-05302010	10 Amp Fuse	1
120	WR05-00000000	Remote Control Module	1
121	GB1667-S5-38	Screw M5×38	3
122	ST05FD-05205009	Control Box	1


Engine Parts Diagram



#	Part Number	Description	Qty.
1	ST160F-1061200	Knob, Recoil Starter	1
2	GB5789-FB6-8	Flange Bolt M6×8	4
3	ST188F-1060100-G	Case, Recoil Assembly	1
4	ST188F-1060009	Return Spring, Recoil Assembly	1
5	ST188F-1060008	Pulley Assembly	1
6	ST188F-1060007	Rope, Recoil Assembly	1
7	ST188F-1060006	Ratchet Spring	2
8	ST188F-1060005	Starter Ratchet	2
9	ST188F-1060004	Spring, Ratchet Guide	1
10	ST188F-1060003	Ratchet Guide	1
11	ST188F-1060002	Bolt, Ratchet Guide	1
12	GB5789-FB6-12	Flange Bolt M6×12	12
13	168FD-1070408-CARB	Hose Clip, CARB	2
14	ST188FD-1080100-G	Fan Cover	1
15	ST188F-1050006	Flywheel Nut	1
16	GB5789-FB6-29	Flange Bolt M6×29	4
17	ST188F-1060001	Starter Hub	1
18	ST188F-1122000-G	Ignition Coil	1
19	ST188F-1080002	Fan Engine	1
20	ST188F-1121000-A	Flywheel	1
21	ST188F-1030002	Plate ,Wire	1
22	ST188F-1123000	Coil, Charging	1
23	ST188F-1030200	Oil Seal	2
24	0902.132001.00	Cover, Stepper Motor	1
25	ST188F-1030001	Clamp Wire	1
26	ST188F-1030012	Sheath Wire	1
27	139FMD-1003101	Drain Plug Bolt	2
28	139FMD-1003102	Drain Plug Washer	2
29	ST188F-1030006-G	Crankcase	1
30	ST188FD-1127000-A	Oil Level Sensor	1
31	GB5789-FB6-15	Flange Bolt M6×15	2
32	GB/T276-94 ST188F-1050303	Radial Ball Bearing 6202/P6 Balance Gear	1
34	GB276-BB-6207-UU	Radial Ball Bearing 6207/C3	2
35	ST188F-1050304		1
36	ST188F-1050304	Key Crankshaft	1
37	ST188F-10300010-G	Gasket, Crankcase	1
38	ST168F-1030015-G	Dowel Pin 9×14	2
39	ST188F-1080002-G	Air Guide, Crankcase	1
40	ST188F-1030003	Oil Dipstick	1
41	ST188F-1030014	Seal	1
42	ST188FD-1031011-G	Crankcase Cover	1
43	GB5789-FB8-40	Flange Bolt M8×40	7
44	ST160F-1110108	Washer, Govorner Gear	1
45	ST188F-1110009	Shaft, Governor	1
46	ST188F-1110101	Governor Gear	1
47	ST188F-1110102	Pin, Governor Weight	3
48	ST188F-1110103	Governor Weight	3
49	ST160F-1110103	Clip, Governor Gear	1
50	ST188F-1110008	Bushing, Governor	1
51	ST188F-1050200	Connecting Rod	1
52	ST188F-1050001	Piston	1
53	ST188F-1050004	Clip, Piston Pin	2
54	ST188F-1050005	Piston Pin	1
55	ST188F-1050100	Oil Ring Set	1
56	ST188F-1050003	Second Ring Set	1
57	ST188F-1050002	First Piston Ring, Chrome	1
58	ST188F-1030013	Dowel pin	2
59	ST188F-1030008-G	Gasket, Cylinder Head	1
60	ST188F-1080001-G	Air Shroud, Cylinder	1
61	ST188F-1011000-G	Cylinder Head	1
62	ST188F-1010001	Exhaust Stud	2
63	F6RTC	Spark Plug	1

#	Part Number	Description	Otv
64	ST188F-1030009		Qty.
65	ST188F-1030009 ST188F-1020003-CPE	Bolt, Cylinder Head Gasket, Cylinder Head	1
66	ST188F-1020100-A	Cylinder Head Cover	1
67	ST188FD-1020002	Breather Tube	1
68	ST188F-1020002	Gasket, Head Cover Bolt	1
69	ST188F-1020005	Washer, Head Cover Bolt	1
70	ST188F-1020006	Bolt , Head Cover	1
71	ST188F-1041000	Camshaft Assembly	1
72	ST188F-1040012	Valve Lifter	2
73	ST188F-1040003	Valve, Intake	1
74	ST188F-1040011	Valve, Exhaust	1
75	ST188F-1040010	Push Rod	2
76	ST188F-1040006	Retainer, Valve Spring	2
77	ST188F-1040004	Oil Seal, Valve	2
78	ST188F-1040007	Valve Spring	2
79	ST168F-1040027	Pivot Bolt	2
80	ST188F-1040002	Retainer Intake Valve	1
81	ST188F-1040008	Retainer Exhaust Valve	1
82	ST188F-1040009	Rotator, Exhaust Valve	1
83	ST188F-1040028	Guide Plate, Push Rod	1
84	ST188F-1040021	Shaft, Rocker Arm	1
85	ST188F-1040026	Retainer, Rocker Arm	1
86	ST188F-1040022	Rocker Arm, Intake Valve	1
87	ST188F-1040023	Rocker Arm, Exhaust Valve	1
88	GB97.1-85	Gasket ø6	2
89	ST160F-1040024	Screw, Valve Adjusting	2
90	GB6177-86-N6	Lock Nut	2
91	ST160F-1040025	Pivot Adjusting Nut	2
92	ST188FD-1010002	Intake Stud	2
93	ST188FD-1130003	Gasket, Carburetor Insulator	1
94	ST188F-1134000	Carburetor Insulator	1
95	ST188F-1130002	Gasket(1), Carburetor	1
96	188.131000.02	Carburetor Assembly	1
97	188.130005.01	Support, Stepper Motor	1
98	ST188FD-1130001	Gasket(2), Carburetor	1
99	ST188FD-1090100-CARB	Case, Air Cleaner	1
100	GB41-N-6	Nut M6	3
101	ST188FD-1090002	Seal, Air Cleaner	1
102	ST188FD-1090003	Separator, Air Cleaner	1
103	ST188FD-1090004	Element, Air Cleaner	1
104	ST188FD-1090200-G	Cover, Air Cleaner	1
105	GB5789-FB8-35	Flange Bolt M8×35	2
106	ST188F-1125000	Starting Motor	1
107	ST188F-1126000	Relay Starter	1
108	GB93-LW-5	Lock Washer ø5	2
109	GB5789-FB5-20	Flange Bolt M5×20	2
110	ST188F-1110003	Shaft Governer Arm	1
111	ST188F-1110005	Washer 8.2×17×0.8	1
112	ST188F-1030100	Oil Seal, Governor Shaft	1
113	ST188F-1110007	Clip, Governor Shaft	1
114	ST188F-1110006	Arm, Governor	1
115	ST160F-1110004	Bolt, Governor Arm	1
116	ST188F-1110002	Rod, Governor	1
117	ST188F-1110001	Spring Throttle Return	1
118	ST188F-1110004	Spring, Governor	1
119	ST188FD-1081000-G	Controller assembly	1
120	ST188FD-1131000-17	Main Jet	1
121	ST188FD-1130001	Gasket(2), Carburetor	1
122	168.130015.01	Connector, Starter	1
123	0902.130010.00	Spring, Connector	1
124	188.132200.00	Stepper Motor Comp.	1
125	GB1667-S4-8	Screw M4×8	2

Wiring Diagram



Problem	Cause	Solution
Generator will not start	No fuel	Add fuel
	Faulty spark plug	Replace spark plug
	Unit loaded during start up	Remove load from unit
Generator starts but runs roughly	Low oil level	Fill crankcase to the proper level
		Place generator on a flat, level surface
	Choke in the wrong position.	Adjust choke.
	Spark plug wire loose	Attach wire to spark plug
Generator shuts down during operation	Out of fuel	Fill fuel tank
	Low oil level	Fill crankcase to the proper level. Place generator on a flat, level surface
Generator cannot supply enough power or overheating	Generator is overloaded	Review load and adjust. See "Power Management"
	Insufficient ventilation	Check for air restriction. Move to a well ventilated area
No AC output	Cable not properly connected	Check all connections
	Connected device is defective	Replace defective device
	Circuit breaker is open	Reset circuit breaker
	Loose wiring	Inspect and tighten wiring connections
	Other	Contact the help line.
Repeated circuit breaker tripping	Overload	Review load and adjust. See "Power Management"
	Faulty cords or device	Check for damaged, bare or frayed wires. Replace defective device

For further technical support:

Technical Service

Mon - Fri 8:30 AM - 5:00 PM (PST/PDT)

Toll Free: 1-877-338-0999

tech@championpowerequipment.com

WARRANTY

CHAMPION POWER EQUIPMENT 2 YEAR LIMITED WARRANTY

Warranty Qualifications

Champion Power Equipment (CPE) will register this warranty upon receipt of your Warranty Registration Card and a copy of your sales receipt from one of CPE's retail locations as proof of purchase.

Please submit your warranty registration and your proof of purchase within ten (10) days of the date of purchase.

Repair/Replacement Warranty

CPE warrants to the original purchaser that the mechanical and electrical components will be free of defects in material and workmanship for a period of one year (parts and labor) and two years (parts) from the original date of purchase (90 days (parts and labor) and 180 days (parts) for commercial & industrial use). Transportation charges on product submitted for repair or replacement under this warranty are the sole responsibility of the purchaser. This warranty only applies to the original purchaser and is not transferable.

Do Not Return The Unit To The Place Of Purchase

Contact CPE's Technical Service and CPE will troubleshoot any issue via phone or e-mail. If the problem is not corrected by this method, CPE will, at its option, authorize evaluation, repair or replacement of the defective part or component at a CPE Service Center. CPE will provide you with a case number for warranty service. Please keep it for future reference. Repairs or replacements without prior authorization, or at an unauthorized repair facility, will not be covered by this warranty.

Warranty Exclusions

This warranty does not cover the following repairs and equipment:

Normal Wear

Generators need periodic parts and service to perform well. This warranty does not cover repair when normal use has exhausted the life of a part or the equipment as a whole.

Installation, Use and Maintenance

This warranty will not apply to parts and/or labor if this generator is deemed to have been misused, neglected, involved in an accident, abused, loaded beyond the generator's limits, modified, installed improperly or connected incorrectly to any electrical component.

Installation, Use and Maintenance Cont'd.

Normal maintenance such as spark plugs, air filters, adjustments, fuel system cleaning and obstruction due to buildup is not covered by this warranty.

Other Exclusions

This warranty excludes:

- Cosmetic defects such as paint, decals, etc.
- Wear items such as filter elements, o-rings, etc.
- Accessory parts such as starting batteries, and storage covers.
- Failures due to acts of God and other force majeure events beyond the manufacturer's control.
- Problems caused by parts that are not original Champion Power Equipment parts.

This warranty does not apply to generators used for prime power in place of a utility.

Limits of Implied Warranty and Consequential Damage

Champion Power Equipment disclaims any obligation to cover any loss of time, use of this product, freight, or any incidental or consequential claim by anyone from using this generator. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

A unit provided as an exchange will be subject to the warranty of the original unit. The length of the warranty governing the exchanged unit will remain calculated by reference to the purchase date of the original unit. This warranty gives you certain legal rights which may change from state to state. Your state may also have other rights you may be entitled to that are not listed within this warranty.

Contact Information

Address

Champion Power Equipment, Inc. **Customer Service** 10006 Santa Fe Springs Rd. Santa Fe Springs, CA 90670 www.championpowerequipment.com

Customer Service

Mon - Fri 8:30 AM - 5:00 PM (PST/PDT) Toll Free:1-877-338-0999 info@championpowerequipment.com Fax no.: 1 (562) 236-9429

Technical Service

Mon - Fri 8:30 AM - 5:00 PM (PST/PDT)

Toll Free: 1-877-338-0999

tech@championpowerequipment.com 24/7 Tech Support: (562) 204-1188

Champion Power Equipment Emissions Control Warranty Statement, engines greater than 80cc

Champion Power Equipment, Inc. (CPE),
The California Air Resources Board (CARB) and the United States Environment Protection Agency (U.S. EPA.)
Emission Control System Warranty

Your Champion Power Equipment (CPE) engine complies with both the U.S. EPA and state of California Air Resources Board (CARB) emission regulations.

YOUR WARRANTY RIGHTS AND OBLIGATIONS:

The California Air Resources Board, US EPA AND CPE are pleased to explain the Federal and California Emission Control Systems Warranty on your 2012 small off-road engine and engine powered equipment. In California, new, small off-road engines and new equipment that use small off-engines must be designed, built and equipped to meet the State's stringent anti smog standards. In the other states, new engines and equipment must be designed, built and equipped, at the time of sale, to meet U.S. EPA regulations for small non-road engines. CPE warrants the emission control system on your small off-road engine and equipment for the period of time listed below, provided there has been no abuse, neglect, unapproved modification, or improper maintenance of your equipment.

Your emission control system may include parts such as the carburetor, fuel-injection system, the ignition system, catalytic converter and fuel lines. Also included may be hoses, belts, connectors and other emission related assemblies. Where a warrantable condition exits, CPE will repair your small off-road engine at no cost to you including diagnosis, parts and labor. For engines less than or equal to 80cc, only the fuel tank and fuel line is subject to the evaporative emission control warranty requirements of this section.

MANUFACTURER'S EMISSION CONTROL SYSTEM WARRANTY COVERAGE:

This emission control system is warranted for two years, subject to provisions set forth below. If, during the warranty period, emission related part on your engine is defective in materials or workmanship, the part will be repaired or replaced by CPE.

OWNER WARRANTY RESPONSIBILITIES:

As the small off-road engine owner, you are responsible for the performance of the required maintenance listed in your Owner's Manual. CPE recommends that you retain all your receipts covering maintenance on your small off-road engine, but CPE cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

As the small off-road engine owner, you should however be aware that CPE may deny you warranty coverage if your small, off-road engine or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

You are responsible for presenting your small off-road engine to an Authorized CPE service outlet or alternate service outlet as described in (3)(f.) below, CPE dealer or CPE, Santa Fe Springs, Ca. as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

If you have any questions regarding your warranty rights and responsibilities, you should contact:

Champion Power Equipment, Inc. Customer Service 10006 Santa Fe Springs Road Santa Fe Springs, CA 90670 1-877-338-0999

EMISSION CONTROL SYSTEM WARRANTY

The following are specific provisions relative to your Emission Control System Warranty Coverage.

1. APPLICABILITY: This warranty shall apply to 1995 and later model year California small off-road engines (for other states, 1997 and later model year engines). The ECS Warranty Period shall begin on the date the new engine or equipment is delivered to its original, end-use purchaser, and shall continue for 24 consecutive months thereafter.

2. GENERAL EMISSIONS WARRANTY COVERAGE

CPE warrants to the original, end-use purchaser of the new engine or equipment and to each subsequent purchaser that each of its small off-road engines is:

- a. Designed, built and equipped so as to conform with all applicable regulations adopted by the Air Resources Board pursuant to its authority in Chapters 1 and 2, Part 5, Division 26 of the Health and Safety Code, and
- b. Free from defects in materials and workmanship that cause the failure of a warranted part to be identical in all material respects to the part as described in the engine manufacturer's application for certification for a period of two years.

3. THE WARRANTY ON EMISSION-RELATED PARTS WILL BE INTERPRETED AS FOLLOWS:

- a. Any warranted part that is not scheduled for replacement as required maintenance in the Owners Manual shall be warranted for the ECS Warranty Period. If any such part fails during the ECS Warranty Period, it shall be repaired or replaced by CPE according to Subsection "d" below. Any such part repaired or replaced under the ECS Warranty shall be warranted for any remainder of the ECS Warranty Period.
- b. Any warranted, emissions-related part which is scheduled only for regular inspection as specified in the Owners Manual shall be warranted for the ECS Warranty Period. A statement in such written instructions to the effect of "repair or replace as necessary", shall not reduce the ECS Warranty Period. Any such part repaired or replaced under the ECS Warranty shall be warranted for the remainder of the ECS Warranty Period.
- c. Any warranted, emissions-related part which is scheduled for replacement as required maintenance in the Owner's Manual shall be warranted for the period of time prior to the first scheduled replacement point for that part. If the part fails prior to the first scheduled replacement, the part shall be repaired or replaced by CPE according to Subsection "d" below. Any such emissions-related part repaired or replaced under the ECS Warranty, shall be warranted for the remainder of the ECS Warranty Period prior to the first scheduled replacement point for such emissions-related part.
- d. Repair or replacement of any warranted, emissions-related part under this ECS Warranty shall be performed at no charge to the owner at a CPE Authorized Service Outlet.
- e. The owner shall not be charged for diagnostic labor which leads to the determination that a part covered by the ECS Warranty is in fact defective, provided that such diagnostic work is performed at a CPE Authorized Service Outlet.
- f. CPE shall pay for covered emissions warranty repairs at non-authorized service outlets under the following circumstances:
- i. The service is required in a population center with a population over 100,000 according to U.S. Census 2000 without a CPE Authorized Service Outlet AND
- ii. The service is required more than 100 miles from a CPE Authorized Service Outlet. The 100 mile limitation does not apply in the following states: Alaska, Arizona, Colorado, Hawaii, Idaho, Montana, Nebraska, Nevada, New Mexico, Oregon, Texas, Utah and Wyoming.
- g. CPE shall be liable for damages to other original engine components or approved modifications proximately caused by a failure under warranty of an emission-related part covered by the ECS Warranty.
- h. Throughout the ECS Warranty Period, CPE shall maintain a supply of warranted emission-related parts sufficient to meet the expected demand for such emission-related parts.
- i. Any CPE Authorized and approved emission-related replacement part may be used in the performance of any ECS Warranty maintenance or repair and will be provided without charge to the owner. Such use shall not reduce CPE's warranty obligation.
- j. Unapproved add-on or modified parts may not be used to modify or repair a CPE engine. Such use voids this ECS Warranty and shall be sufficient grounds for disallowing an ECS Warranty claim. CPE shall not be liable hereunder for failures of any warranted parts of a CPE engine caused by the use of such an unapproved add-on or modified part.

EMISSION-RELATED PARTS INCLUDE THE FOLLOWING: (using those portions of the list applicable to the engine)

Systems covered by this warranty	Parts Description
Fuel Metering System	Fuel regulator, Carburetor and internal parts
Air Induction System	Air cleaner, Intake manifold
Ignition System	Spark plug and parts, Magneto ignition system
Exhaust System	Exhaust manifold, catalytic converter
Miscellaneous Parts	Tubing, Fittings, Seals, Gaskets, and Clamps associated with these listed systems.
Evaporative Emissions	Fuel Tank, Fuel Cap, Fuel Line, Fuel Line Fittings, Clamps, Pressure Relief Valves, Control Valves, Control Solenoids, Electronic Controls, Vacuum Control Diaphragms, Control Cables, Control Linkages, Purge Valves, Vapor Hoses, Liquid/Vapor Separator, Carbon Canister, Canister Mounting Brackets, Carburetor Purge Port Connector

TO OBTAIN WARRANTY SERVICE:

You must take your CPE engine or the product on which it is installed, along with your warranty registration card or other proof of original purchase date, at your expense, to any Champion Power Equipment dealer who is authorized by Champion Power Equipment, Inc. to sell and service that CPE product during his normal business hours. Alternate service locations defined in Section (3)(f.) above must be approved by CPE prior to service. Claims for repair or adjustment found to be caused solely by defects in material or workmanship will not be denied because the engine was not properly maintained and used.

If you have any questions regarding your warranty rights and responsibilities, or to obtain warranty service, please write or call Customer Service at Champion Power Equipment, Inc.

Champion Power Equipment, Inc. 10006 Santa Fe Springs Road Santa Fe Springs, CA 90670 1-877-338-0999 Attn.: Customer Service